



ELDER VALVE DETAIL



TRAPSTOP STYLE SEWER VALVE



ELDER STYLE SEWER VALVE

NOT TO SCALE

NOTES:

1. WHERE TOWN OF LEXINGTON IS NOT THE WATER PROVIDER A SEWER VALVE SHALL BE INSTALLED AT PROPERTY LINE OR SEWER MAIN EASMENT.
2. ALL SEWER SERVICE LINES AND CONNECTIONS MUST BE VISUALLY INSPECTED BY THE TOWN OF LEXINGTON UTILITY DEPARTMENT (803 359-2434) BEFORE ANY PORTION OF SERVICE LINE IS COVERED WITH BACKFILL.